

# AquaLink® RS OneTouch™ Quick Review Card

**Basic Operation:** The AquaLink® RS One Touch™ Indoor Control panel can turn your pool/spa/landscape equipment on and off three ways:

❶ You can manually activate equipment through the EQUIPMENT ON/OFF menu. ❷ You can use the ONETOUCH ON/OFF menu which allows you to turn on multiple items at once with just “one touch” of a button. For example, spa heater at 101°, spa light on, jets activated, and water features on and name it ‘Moms Spa’. ❸ Under MENU/HELP you can program the equipment to turn on and off at specific times. See Owners Manual for detailed instructions. **Note:** The AquaLink® RS One Touch™ has two default screens; Date/Time/Temp Screen or the OneTouch Screen. The OneTouch will return to the Date/Time/Temp Screen after 30 seconds of inactivity. The display rotates between the Date/Time/Temp Screen and the Equipment Screen to show which equipment is ON.

## OneTouch Buttons

Navigates screens or activates OneTouch feature on screen ❷.

## Arrow Buttons

Move the highlight or value up & down.

❶



❷



❸



→ **“Equipment” Screen**  
 Activate equipment manually. Use ARROW buttons to highlight any equipment then press SELECT. ONETOUCH buttons *navigate*:

→ **“OneTouch” Screen**  
 Activate multiple pieces of programmed equipment with “one touch”. ONETOUCH buttons *activate* - in the sample above:

→ **“Menu/Help” Screen**  
 Program your equipment start and stop times, set the temperature as well as activate many of the powerful features of your OneTouch Control System.

Page Up



Night Party



Back a Screen



Moms Spa



Page Down



Clean Mode



## Select Button

Activates the highlighted item.

## Heater LED

When Green, indicates enabled or up to temperature. Red indicates heater is on and firing.



# AquaLink® RS OneTouch Programming & System Defaults

**Basic Operation:** After powering up the AquaLink® RS One Touch™ indoor control panel, the first screen will be the Date & Time Menu. (If you see a screen displaying “SYSTEM” at the bottom, press select.) From this main screen you can program the system to your specifications. To review button operation, select MENU/HELP, HELP, then KEYS. When moving through the screens, you will have about 45 seconds before the controller will return to the previous menu.

**Set the Time:** Highlight MENU/HELP, press select, highlight SET TIME and press select. Use up/down arrows to pick numbers and select button to set time.

**Set the Temperature:** Highlight MENU/HELP press select, highlight SET TEMP and press select. Inside the SET TEMP menu, use the up/down arrows to highlight either pool or spa and press select. Use the up/down arrows to increase or decrease the temperature.

**Basic Programing:** To set a particular piece of equipment to turn on and off at predetermined times, highlight MENU/HELP and press SELECT. Highlight PROGRAM and press SELECT. Use the up/down arrows to highlight the equipment you want to program, Press SELECT and follow the on screen prompts. Use the up/down arrows to select a value. If you make a mistake use the BACK button. If the program is already entered, highlight CHANGE PROGRAM and move to the entry you want to change. Use the page up / page down buttons to choose among programs.

**Equipment On/Off:** From the Date & Time screen, highlight EQUIPMENT ON/OFF and press select. To highlight an item, use the up/down arrows, then press the SELECT button to turn the equipment on or off. After turning a piece of equipment on, return to the main menu by using the back button.

**Label Auxiliary Functions:** Highlight MENU/HELP press select, highlight SYSTEM SETUP press select, highlight LABEL AUX press select. Highlight an AUX and press select. You can choose a name from general, light or waterfall labels or enter a custom label.

**One Touch Button Set-Up:** There are three OneTouch buttons for custom configuration. You can select a predetermined name from the “select name” menu or enter a “custom name”. Highlight MENU/HELP, press SELECT, highlight SYSTEM SETUP, press SELECT, highlight ONE TOUCH, press SELECT, highlight one of the three and press SELECT. Use the up/down arrows to choose either SELECT NAME or CUSTOM NAME and press SELECT. (For Custom Name use the up/down arrows to change letters.) Choose SET DEVICES from the ONETOUCH SETUP menu, press SELECT. Use the up/down arrows to move to equipment you want on, press SELECT. When all items desired are selected press BACK to set up the next OneTouch Button.

## Default Temperature

Default Pool Temp. 80°F

Default Spa Temp. 102°F

Default Temp. 1\* 80°F

Default Temp. 2\* 60°F

\*Pool only / Spa only systems

## Default Remote Settings

Button 1 - Spa (Filter Pump)\*

Button 2 - Spa Heater (Temp 1)\*

Button 3 - AUX 1

Button 4 - AUX 2

\*Pool/Spa combination systems

## Default Freeze Protection Settings

Filter Pump: Freeze Protection ON.

All other Equipment: Freeze Protection OFF

NOTE: If you selected Spa to be freeze protected, water circulation will switch between pool and spa every 30 minutes during freezing pool and spa every 30 minutes during freezing conditions once freeze mode is active.